

Dash Mount Filter Minder® Gauge

Installation Instructions:

1. Remove screws from bezel.
2. Position Filter Minder® gauge behind 2" instrument panel hole.
3. Position bezel at front of instrument panel with reset button lined up through rectangular slot in bezel.

4. Tighten bezel to Filter Minder® gauge.
5. Attach vacuum hose to clear push on stem in back of gauge. Route to the air cleaner tap and attach to barbed fitting.

The Filter Minder® is now ready to monitor the air cleaner system. The gauge gives a progressive indication of air filter plugging which allows the entire air filter capacity to be used. Many air cleaner systems will show very little restriction for 50,000 miles or more. Do not be alarmed! Many on-highway trucks get 200,000 to 300,000 miles air filter service life. Actual filter service life will depend on operating conditions.

