

## Remote Mount Filter Minder® Indicator



### Installation Instructions:

1. Mount in cab or engine compartment. For mounting holes use a no. 29 drill bit (0.136"). Mounting screws enclosed.
2. Push hose on gauge and route to air cleaner tap.
3. Install barbed fitting in air cleaner tap. (A female elbow may be required if the air cleaner has a male welded-in tap.) Use pipe sealant on all metal fittings.
4. Cut off surplus hose and push on to barbed fitting.

The Filter Minder® is now ready to monitor the air cleaner system. The indicator gives a progressive indication of air filter plugging which allows complete air filter capacity to be used. Many air cleaner systems will show very little restriction for 50,000 miles or more. Do not be alarmed! Many on-highway trucks get 200,000 to 300,000 miles air filter service life. Actual filter service life will depend on operating conditions.

